

HP Media Center PC  
Quick Setup  
快速装配示意图



© 2004 Hewlett-Packard Development Company, L.P.


Printed in

www.hp.com



5 9 9 1 - 1 3 4 8

1 Keyboard and Mouse  
键盘和鼠标



OR  
或者

Wireless option

Refer to the set up instructions located in your mouse/receiver box.


无线装置

请参考鼠标/接收器包装盒中的安装说明。



2 Remote Control  
遥控器

Install AA batteries in remote control.  
将两节 AA 电池装入遥控器。




3 Monitor  
显示器

Refer to setup instructions that came with your monitor.

显示器

请参考显示器附带的安装说明。




4 Speakers  
扬声器


Refer to setup instructions that came with your speakers.

扬声器

请参考扬声器附带的安装说明。




5 TV In Connect TV signal to computer  
通过 TV In 将电视信号接入电脑



OR  
或者

If you use a cable or satellite set-top-box, pass the signal through the box.  
如果您使用有线电视或卫星电视机顶盒，请通过机顶盒接入信号。


Cable or satellite set-top-box  
有线电视或卫星电视机顶盒



6 TV Out (TV connections are optional)  
TV Out (电视连接是可选的)

TV signal from computer to TV

将电视信号从电脑接入电视




Composite video cable to S-video adapter  
复合视频电缆转 S-Video 适配器

7 Remote Sensor  
遥控器

Connect remote control receiver to computer.

将遥控器接收器连接到电脑。



OR  
或者

If you use a cable or satellite set-top box, pass the signal through the remote sensor control cable.  
如果您使用有线电视或卫星电视机顶盒，请通过遥控器控制电缆接入信号。

Cable or satellite set-top-box  
有线电视或卫星电视机顶盒

